



USING OUR POPCORN MACHINES

Now that Get Slush'd have set the Popcorn machine up.

1. Turn power on from the power inlet.
2. Turn on the "MASTER" switch (Located inside top left, BIG switch); this will turn the interior light on and the warming element located in the bottom of the unit (under the stainless steel base)
3. Turn on the "KETTLE" switch (Located next to the Master switch), this will heat the kettle and activate the agitating motor. Allow 5 minutes for the kettle to reach operating temperature.
4. Our Popcorn machine is ready for you to START POPPING CORN.
5. Add in 1 Bag Popcorn kernels, 1 Sachet of oil and 1 pkt of seasoning.
6. Once kernels have stopped "popping" simply release the kettle by turning the handle clockwise and slowly lowering.
7. Repeat step 5 to continue popping more batches of kernels.
8. When you have stopped using the machine for any prolonged period (5 mins), turn off the kettle by the switch listed in step 3 and with a damp cloth wipe the inside of the kettle to remove any oil left, this will stop the oil from burning onto the kettle.
9. You can leave the "MASTER" switch on as this will keep any popped corn left in the base fresh and warm from the element, the light will also remain ON as a reminder that the Master switch is still on.
10. When completely finished using the machine wipe the inside and outside of the kettle with a damp cloth to remove any oil to stop it from burning onto the surface of the kettle, please ensure both switches are off, then unplug ready for collection.



CLEANING INCLUDED: However we would appreciate if you could remove any popcorn left from inside the machine and any kernels from the drawer.

WHEN IN OPERATION ALL SURFACES WILL BE HOT, PLEASE KEEP CHILDREN AWAY FROM ANY HOT SURFACE AND HANDLE WITH CARE